



1500 Cherokee Parkway, Suite 100, Acworth, GA 30102
P: 866-845-5451 • F: 866-816-6165
E: service@acclaim-lighting.com • www.acclaim-lighting.com

Item No . TW6600 INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.
Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

1. Remove the shade (18) from backplate(15).
2. Remove the two ball finials (16) and remove crossbar (5) from backplate (15).
3. Thread two mounting screws (7) to the crossbar (5) and secure with the hex nut (8). Attach crossbar (5) to outlet box (1) using two box screws (6) provided with the outlet box. (Note: if the box screws with the outlet box are too short, use the 8-32 x 1" screws provided in the mounting hardware package).
4. Connect the white or ribbed fixture wire (12) to the white supply wire (3) in the outlet box using the twist-on wire connector (9) provided. Connect the black or smooth fixture wire (11) to the black supply wire (2) in the same manner. Install the fixture ground wire (13) and supply ground wires (4) onto the crossbar using the green ground screw (10) and wire connector.
5. Raise fixture (14) to the wall and carefully tuck the wires inside the outlet box (1). Spread the electrical splices so that the black wires are on one side of the outlet box and the white wires are on the other side. Line up mounting screws (7) with holes in backplate (15) and secure with ball finials (16).
6. Install a 60 watt candelabra base type "B" bulb (not included) into socket (17).
7. Place shade (18) onto backplate (15) and secure ball screws (19) .

INSTALLATION IS NOW COMPLETED

